

Load Chart AR-1600M (เครื่อง 160 ตัน)

Outriggers fully extended (8.8 m)							
B \ A	13.5m	18.1m	22.6m	31.8m	40.9m	45.4m	50.0m
3.2m	160.00	110.00	100.00				
3.5m	151.70	110.00	100.00				
4.0m	139.60	110.00	100.00				
4.5m	129.30	110.00	100.00				
5.0m	118.80	110.00	100.00				
6.0m	86.90	97.00	90.00	65.00			
7.0m	76.20	86.10	81.40	65.00	50.00		
8.0m	67.60	75.60	71.80	59.60	50.00	42.00	
9.0m	62.00	67.40	65.90	54.50	47.30	42.00	30.00
10.0m	51.40	60.20	58.80	50.40	44.50	38.80	30.00
11.0m		54.20	52.80	46.90	41.80	36.00	30.00
12.0m		49.40	47.30	43.30	38.50	34.50	30.00
14.0m		40.70	38.70	37.20	32.60	30.20	26.40
16.0m		23.90	32.30	31.60	28.50	26.50	23.30
18.0m			27.80	27.60	25.00	23.10	20.70
20.0m			20.20	24.10	21.80	20.70	18.40
22.0m				20.20	19.10	18.20	16.60
24.0m				17.10	17.00	16.40	14.80
26.0m				14.60	15.10	14.70	13.30
28.0m				12.60	13.20	13.10	12.00
30.0m					11.40	11.60	10.80
32.0m					9.90	10.20	9.60
34.0m					8.80	8.90	8.60
36.0m					7.70	7.80	7.60
38.0m					6.50	6.70	6.70
40.0m						5.90	6.00
42.0m						5.10	5.20
44.0m							4.50
46.0m							3.90
47.0m							3.60
a (°)	0 - 83			10 - 83	1 - 83	12 - 83	12 - 83

A = ระยะยึดบูม B = ระยะห่างตัว a คือ องศากระดานบูม